



6-Pin Wire Harness Assembly Installation Guide


Connect leads as shown per your service part number.
An adapter wire, illustrated, may be required when connecting
the alternator system.



698330 – Models 400000/440000 OHV (See also 696576)




696576 – Models 400000/440000 OHV (Models equipped with Engine Minder™)




(over)

698329 – Models 280000 & 310000 OHV and L-Head



698332 – Models 290000, 300000, 350000, & 380000 OHV Vanguard™ Series



698331 – Models 420000 & 460000

